Polaroid

SHUTTER STICK COMBO

PMK10 | USER MANUAL

Questions? Need some help? This manual will help you enjoy your new product

If you still have questions, call our help line: 1-877-768-8481

or visit us at: www.southerntelecom.com Click on "Product Support"

Caution: Any changes or modifications not expressly approved could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RECYCLE 1.800.822.8837

PLR IP Holdings, LLC is licensed and affiliates, fully support all electronic waste materials. As responsible stewards of the environment, and to avoid violating established laws, you should properly dispose of this product in compliance with all applicable regulations, directives or other governances in the area where you reside. Please check with local authorities or the retailer where you purchased this product to determine a location where you can appropriately dispose of the product.

Patent(s) recognizable. Instantly. Trademarks, trade dress, Polaroid Classic Border, Frameworthy Polaroid Classic Border, Know you've purchased a product that exemplifies the best qualities of our brand and that contributes to our rich heritage of quality and innovation.

IN THE BOX

Shutter Stick, Car Charger, and Earbuds

User Manual

TROUBLESHOOTING

My smartphone doesn't take photos when the shutter button is pressed.

1. Make sure that your smartphone's camera app is open.
2. Properly secure your smartphone into the smartphone clamp.
3. Check that the 3.5mm headphone adapter is properly secured to your smartphone's headphone jack.
4. Certain smartphones camera apps have default settings that cannot be changed. A third party camera app with a volume key enabled shutter is recommended.

The volume screen appears when I press the shutter button.

The Shutter Stick uses your Smartphone's volume frequency to take photos. If this happens, open your smartphone's CAMERA APP settings select "Volume Button Options" and select CAPTURE. Now the Shutter Stick will take pictures.

LOCATION OF CONTROLS



1. Shutter button
2. Smartphone clamp
3. Shutter Stick tightening wheel
4. 3.5mm headphone adapter

LIABILITY DISCLAIMER

IN NO EVENT, UNDER ANY CAUSE OF ACTION OF THEORY OF LIABILITY, SHALL SOUTHERN TELECOM ITS DISTRIBUTORS OR SUPPLIERS BE LIABLE TO YOU OR ANY THIRD PARTY FOR ANY INDIRECT, INCIDENTAL, CONSEQUENTIAL, SPECIAL, EXEMPLARY OR PUNITIVE DAMAGES, OF ANY NATURE WHATSOEVER, ARISING OUT OF THE USE OF OR INABILITY TO USE ANY SOUTHERN TELECOM PRODUCT, INCLUDING, WITHOUT LIMITATION, PROPERTY DAMAGE, LOSS OF VALUE OF THE SOUTHERN TELECOM PRODUCT OR ANY THIRD PARTY PRODUCTS THAT ARE USED IN OR WITH THE SOUTHERN TELECOM PRODUCT, OR LOSS OF USE OF THE SOUTHERN TELECOM PRODUCT OR ANY THIRD PARTY PRODUCTS THAT ARE USED IN OR WITH THE SOUTHERN TELECOM PRODUCT, EVEN IF SOUTHERN TELECOM HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. WITHOUT LIMITING THE FOREGOING, YOU UNDERSTAND AND AGREE THAT SOUTHERN TELECOM HAS NO LIABILITY FOR ANY DAMAGE OR DESTRUCTION TO CONSUMER ELECTRONICS DEVICES OR OTHER PERSONAL PROPERTY THAT ARE CONTAINED INSIDE OR OUTSIDE THE SOUTHERN TELECOM PRODUCTS, INCLUDING, WITHOUT LIMITATION, LAPTOPS, CELLULAR PHONES, OR OTHER HANDHELD DEVICES, OR ANY LOSS OF DATA CONTAINED IN THE FOREGOING DEVICES. NOTWITHSTANDING ANY DAMAGES THAT YOU MIGHT INCUR FOR ANY REASON WHATSOEVER (INCLUDING, WITHOUT LIMITATION, ALL DAMAGES REFERENCED HEREIN AND ALL DIRECT OR GENERAL DAMAGES IN CONTRACT, TORT (INCLUDING NEGLIGENCE) OR OTHERWISE), THE ENTIRE AGGREGATE LIABILITY OF SOUTHERN TELECOM AND ANY OF ITS DISTRIBUTORS AND/OR SUPPLIERS SHALL BE LIMITED TO THE AMOUNT ACTUALLY PAID BY YOU FOR THE SOUTHERN TELECOM PRODUCT GIVING RISE TO LIABILITY. SOME STATES AND/OR JURISDICTIONS DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATIONS OR EXCLUSIONS MAY NOT APPLY TO YOU. THE LIMITATIONS

USING THE SHUTTER STICK

1. Place your smartphone into the Smartphone clamp. The spring clamp will keep your phone securely in place.



2. Loosen the knob on the base to adjust the angle then tighten it to secure the clamp on the base.



3. Connect the 3.5mm headphone adapter into your smartphone's headphone port.



LIMITED WARRANTY

This product as supplied and distributed new by AIT, Inc. ("AIT") to the original consumer purchaser is warranted by AIT against defects in material and workmanship for a period of one year from your date of purchase ("Warranty").
In the unlikely event that this product is defective, or does not perform properly, you may within one year from your original date of purchase return it to the authorized service center for repair or exchange.

TO OBTAIN WARRANTY SERVICE:
- Call the Customer Support number located below, or go to our website portal to receive an SRO number.
- Provide proof of the date of purchase within the package (Dated bill of sale).
- Prepay all shipping costs to the authorized service center, and remember to insure your return.
- Include a return shipping address (no P.O. Boxes), a telephone contact number, and the defective unit within the package.
- Describe the defect or reason you are returning the product.

Your product will be repaired or replaced, at our option, for the same or similar model of equal value if examination by the service center determines this product is defective. Products received damaged as a result of shipping, will require you to file a claim with the carrier.

The shipping address of the authorized service center is:

AIT, Inc.
ATTN: Customer Service (2nd Floor)
14-C 53rd Street
Brooklyn, NY 11232

IN NO EVENT WILL AIT, ITS MANUFACTURERS, DISTRIBUTORS OR PLR IP HOLDINGS, LLC BE LIABLE FOR ANY INCIDENTAL, DIRECT INDIRECT SPECIAL, PUNITIVE OR CONSEQUENTIAL DAMAGES (SUCH AS, BUT NOT LIMITED TO, DAMAGES FOR LOSS OF PROFITS, BUSINESS, SAVINGS, DATA OR RECORDS) RELATED TO THIS PRODUCT, EXCEPT AS STATED HEREIN, NO OTHER WARRANTIES SHALL APPLY.

Questions? Need some help? This manual will help you enjoy your new product

If you still have questions, call our help line: 1-877-768-8481

or visit us at: www.southerntelecom.com Click on "Product Support"

USING THE SHUTTER STICK (cont'd)

4. Open the camera app on your smartphone.

NOTE: Certain smartphones camera apps have default settings that cannot be changed. A third party camera app with a volume key enabled shutter is recommended.

5. In your smartphone's camera app, select your front facing (Selfie) camera.

NOTE: You can take "Selfies", take normal pictures, or record videos. Choose the settings in your smartphone's camera app.

6. Extend the Shutter Stick to the desired length.

7. Focus on yourself and press the shutter button on the Shutter Stick.

IMPORTANT: Some Android phones will display the volume control screen when the Shutter Button is pressed. This is because the Shutter Stick uses the volume frequency to take photos. If this happens, open your smartphone's CAMERA APP settings select "Volume Button Options" and select CAPTURE. now the shutter will take pictures.